

Please read before using this product

Thank you for buying our Hand box.

Hand box types PM16C-HDX2 (HDX, HDX16) are for use with controllers PM16C-04XD (04XDL, 16, 16HW, 16EC); and can't be used with PM16C-02 series controllers, or PM16C-04 (04S).

Before connecting Hand box to a controller, Hand box type must be set in controller's settings menu.

Factory Hand box type setting is PM16C-HDX. If you have different type of Hand box, please adjust the settings as described below.

How to set Hand box type

- ① Make sure what controller is in LOCAL mode. (Change mode with REM/LOC button if necessary.)
- ② Press SETUP button, when select setting's page using JOG switch.
CW : Next page
CCW : Previous page

- ③ On appropriate page set Hand box type to what you have.

Controller type	Page number	Setting entry
PM16C-04XD	P8	HAND BOX CONTROL
PM16C-04XDL	P9	HAND BOX CONT
PM16C-16,16HW,16EC	P9	HAND BOX CONT

Hand box type	Setting
PM16C-HDX2	02TYPE
PM16C-HDX	04TYPE
PM16C-HDX16	16TYPE

Factory setting: 04TYPE

- ◆ Please consult with your controller's user's manual for Hand box usage.

PM16C-04XD : Local control user's manual 5.5 Hand box control
PM16C-04XDL : Local control user's manual 5.3 Hand box control
PM16C-16,16HW,16EC : User's manual 4.6 Hand box (Optional)



APPLICATION OF ELECTRONIC DEVICES
TSUJI ELECTRONIC CO., Ltd.

Tsuchiura-city Kandatsu-machi 3739
300-0013 Ibaraki JAPAN

TEL.029-832-3031 FAX.029-832-2662

URL <http://www.tsujicon.jp/> E-mail info2@tsuji-denshi.co.jp